

MAP GUIDE

Map 0: --Disables BMS Power BOX, all signals pass through

Map 1: --30% Throttle Remapping, Performance Tuning (ON)

Map 2: --60% Throttle Remapping, Performance Tuning (ON)

Map 3: --100% Throttle Remapping, Performance Tuning (ON)

Map 4: --30% Throttle Remapping, Performance Tuning (OFF)

Map 5: --60% Throttle Remapping, Performance Tuning (OFF)

Map 6: --100% Throttle Remapping, Performance Tuning (OFF)

Map 7: --Throttle Remapping Disabled, Performance Tuning (ON)

Map switching directions:

Insert keyfob and press start button to turn ignition on (lights on dash, but engine not running). Press and hold the gas pedal down to the floor for 4 or more seconds, and then release pedal. This puts the BMS Power Box in to listen mode. If you start the engine at this point you will be on map 0. For performance maps press the gas pedal to the floor and quickly release one time for each map you would like to select. For example for map 3 press and release the gas 3 times, and start the engine. Your map setting will be saved until changed. If you forget what map you are on, turn engine off and reset the map selection.